



Subfloor gap must be installed or cutback 1/2" from the threshold, of the vinyl door. This is to protect the door from expansion of wood which could cause the warping or twisting of the sill. This requirement should be minimum requirement for cut back, please consult your subfloor manufacturer for further information.

Flooring joist and decking requirements vary from job to job. Win-Dor requires that a solid surface exist, continually, under the door for threshold support. Support must be able to handle the weight of the door. Use 7 lbs. per square foot for your weight calculations.

450 Delta Ave  
Brea, Ca 92821  
(714) 385-1202



Notice: This document contains information proprietary to and is protected by copyright of Win-Dor Inc. and shall not be copied, disclosed to others, or used for any purpose other than that for which it is given, without the written permission of Win-Dor Inc.

<b>Project:</b>	<b>File name: 3750 Swing Door Outswing Subfloor Cutback Detail - 1 inch Nail-fin</b>	<b>Date: 20230913</b>
<b>Notes:</b>	<b>Layout: Wood Sub-floor Cutback</b>	<b>Drawn by: D Deschner</b>