

3750 Flush Handle Lock Reversal

Estimated Time to Reverse 4-7 Minutes



The purpose of this document is to provide users with a quick and easy explanation of how to switch the direction of the 3750 flush handle lock when you engage the thumb slide.

Figure 1

Step 1. Remove lock and flip it around exposing the back of the interior plate. There is an oval shaped stainless-steel plate with 3 washer head screws. For this reversal the top and bottom screw are our only concern (Fig.1).

Step 2. Loosen both screws shown in figure 1 but do not remove. Just loosen enough to allow you to turn the plastic dial below the stainless-steel plate.

Step 3. Turn both plastic dials (Fig.2) under the stainless-steel plate so that the pegs that are in between the oval slots end up in the oval slot opposite where they started (Fig.3).



Figure 2



Figure 3

Step 4. Tighten the 2 screws you loosened at the beginning and reinstall the hardware.

You're all set!